

## Wedge Use Instructions

### **Installing The Anti-Rattle Hitch Wedge**

1. Insert Receiver Plug (C) into Hitch Receiver.
2. Insert the Stabilizer Bracket (Q) and one Large Flat Washer (L) on the threaded portion of the Offset Eyebolt (R).
3. Thread one 5/16-18 Nut (K) approximately  $\frac{1}{4}$ " on the Offset Eyebolt (R).
4. Insert a Hitch Pin (not included) through the eye of the Offset Eyebolt (R) and into the pin hole of the Hitch Receiver.
5. Secure the Hitch Pin with a Hitch Pin Clip (not included).
6. Insert the angle edge of the Stabilizer Bracket (Q) into the gap between the inside of the Hitch Receiver and the Receiver Plug (C).
7. Tighten the 5/16-18 Nut (K) so the angled edge of the Stabilizer Bracket (Q) wedges between Receiver Plug (C) and Hitch Receiver. This eliminates any play between the Hitch Plug and Hitch Receiver.

